

# **BL100 Fingerprint Lock User Manual**

---

**Version: 1.0**

**Date: March 2012**

## **About This Manual**

This manual introduces the fingerprint lock interface and menu operations about BL100. For the fingerprint lock installation, see the animated installation instructions.

## **Important Claim**

Firstly thank you for purchasing this product, before use, please read this manual carefully to avoid the unnecessary damage! The company reminds you that the proper user will improve the use affect and authentication speed.

No written consent by our company, any unit or individual isn't allowed to excerpt, copy the content of this manual in part or in full, also spread in any form.

The product described in the manual maybe includes the software which copyrights are shared by the licensors including our company, Except for the permission of the relevant holder, any person can't copy, distribute, revise, modify, extract, decompile, disassemble, decrypt, reverse engineering, leasing, transfer, sub-license the software, other acts of copyright infringement, but the limitations applied to the law is excluded.



Due to the constant renewal of products, the company can not undertake the actual product in consistence with the information in the document, also any dispute caused by the difference between the actual technical parameters and the information in this document. Please forgive any change without notice.

## Table of Contents

1	Instruction for Use .....	- 1 -
1.1	Introduction to Fingerprint Lock Functions.....	- 1 -
1.2	Front and Rear Views .....	- 2 -
1.3	Precautions.....	- 3 -
1.4	User Privileges.....	- 4 -
1.5	Finger Placement .....	- 5 -
2.	The Basic Operation .....	- 6 -
2.1	Change Master Pass Code (MPC) .....	- 6 -
2.2	Enroll an Administrator .....	- 7 -
2.2.1	Enroll a Fingerprint Administrator User .....	- 7 -
2.2.2	Enroll a Password Administrator User.....	- 8 -
2.3	Enroll an ordinary User .....	- 9 -
2.3.1	Enroll a Fingerprint Ordinary User.....	- 9 -
2.3.2	Enroll a Password Ordinary User .....	- 10 -
2.4	User Verification.....	- 11 -
2.4.1	The Fingerprint Verification.....	- 11 -
2.4.2	The Password Verification .....	- 12 -
2.5	Delete User .....	- 12 -
2.5.1	Delete a user .....	- 12 -
2.5.2	Delete All Ordinary Users.....	- 13 -
2.6	Enable / Disable a User.....	- 14 -
2.7	Reset Lock to Factory Default Settings .....	- 14 -
3	Conventions on Other Functions .....	- 16 -
3.1	Routine Operation Indications .....	- 16 -
3.2	Initialization Lock.....	- 16 -
3.3	Unlock the Non-lock Status Alarm.....	- 17 -
3.4	Automatic Program Exit and System Power-off.....	- 18 -


3.5 Use Description of External Power .....	- 18 -
3.6 Unlock With an Emergency Mechanical Key.....	- 19 -
3.7 Battery Low Voltage Protection.....	- 20 -
4. Appendix.....	- 22 -
4.1 The Parameter Table .....	- 22 -
4.2 Statement on Human Rights and Privacy .....	- 23 -
4.3 Environment-Friendly Use Description.....	- 25 -

# 1 Instruction for Use

## 1.1 Introduction to Fingerprint Lock Functions

1. By leveraging the perfect combination of biometrics and cryptography, our fingerprint locks ensure security through the fingerprint and password unlocking feature.
2. Use the keyboard to finish all relevant operations according to the signals of the buzzer and indicator light. You can simply use our fingerprint locks with ease after following the operation instructions for once.
3. Support setting of classified privileges for administrators and ordinary users.
4. Support deletion of all or the specified registration data.
5. Fingerprint verification module and password registration; 1: N is used for the password, and each password is unique.
6. Support a temporary connection with back-up batteries.
7. Support generation of low-pressure alarms.
8. **Non-lock Status Alarm Function:** A non-lock status is the lock bolt does not pop out normally caused by mechanical breakdown or failure in closing the door after users pass the verification and open the door. In this situation, the buzzer will sound a short sharp alarm which will last one minute unless the alarm is manual remove.

## 1.2 Front and Rear Views



① **Fingerprint Collector:** You can only collect or match fingerprints by pressing your finger(s) at the fingerprint sensor when the light in the fingerprint sensor window goes on; otherwise nothing happens when you press your finger(s) at the fingerprint sensor.

② **Start key /LED Status indicator:** This key can be used to start the fingerprint lock. Press and hold this key on the initial interface to enter the Verify State of Management Mode.

③**Number keys:** Used for input passwords or user ID.

④**Key Hole:** You can use a mechanical key for emergency door opening.

⑤**Emergency power interface:** You can use a mechanical key for emergency door opening.

**LED Backlight Indicators:**

The LED Backlight Indicators content three colors: Red, Green and Blue.

**The general rule:**

**Successful** = 1 Long Beep / LED Flashes Green.

**Failed** = 2 Short Beeps / LED Flashes Red.

**Verify State:** Green LED flash by second.

**Management Mode:** Blue LED flash by second.



All lock functions should return as above, if not, please contact our businessman or technician.

### 1.3 Precautions

1. User must change Master Pass Code (MPC) when they 1st install the Lock. See Change MPC section and user must have at least one administrator user registered before adding ordinary user. If you don't change the MPC, can't use any function except the initial system. If you don't register Administrator, then you can't add ordinary user.

2. Do not remove batteries when matching, enrolling or deleting fingerprints because

the sudden power-down may result in data loss of fingerprint locks. Prior to removing batteries, make sure the fingerprint lock is not in working state.

**3.** It is recommended to replace the fingerprint lock batteries at least once every six months to avoid damaging the circuit due to the battery leakage. Do not use batteries with poor quality.

**4.** When installing a fingerprint lock, connect the plug to the socket properly. Improper connection may lead to fingerprint lock failure.

## **1.4 User Privileges**

The user privileges are classified into **two** types: Administrator users and Ordinary users.

**Administrator (Admin):** Refer to users who have access to all operations like settings and enrolling user.


**Ordinary user:** Refer to all users other than the administrators. Ordinary users only have access to the fingerprint matching and unlocking functions.



## 1.5 Finger Placement

**Recommended fingers:** The index finger, middle finger or the ring finger is recommended; the thumb and little finger are not recommended (because they are usually clumsy when pressing on the fingerprint collection screen).


### 1. Proper finger placement




**The finger must be flat to the surface and centered on the fingerprint sensor.**

### 2. Improper finger placement


**Not flat to the surface**




**Off-center**



**Slanting**



**Off-center**



Please enroll and verify your fingerprint by using the proper finger placement mode. We shall not be held accountable for any consequences arising out of the degradation in verification performance due to improper user operations. We shall reserve the right of final interpretation and revision of this document.

## 2. The Basic Operation

### 2.1 Change Master Pass Code (MPC)


 **Notice:**



(1) User must change Pass code when they 1st install the Lock, otherwise you can't register administrator.




(2) User must have registered at least one administrator user before enrolling ordinary user, or you can't enroll.

(3) All lock operation should have an operation time limit of 10 seconds.

To change **MPC**, the procedure show as follows:

1. Press  key to start lock, and then enter the Verify State. The LED flashes green light.

2. Press and hold the  key until you hear 1 long beep and the Green LED put out, and then the Keypad area Flashes Blue light. Press number key of the lock to input the default **MPC** "98989", and then press  key to enter the Management Mode.




3. Press "5" key on the lock and enter the new 5 digits **MPC**, then press the  key to confirm. Enter the new MPC once again then press the  key to confirm. Once you hear 1 long beep and the  key flashes green, namely you

have successfully changed the MPC code.

### 2.2 Enroll an Administrator

The lock has two kinds user: Administrator User and Ordinary User. If the fingerprint lock has no administrator, then you can't enroll ordinary users. So you must at least enroll one administrator before enrolling ordinary users.

To enroll administrator, proceed as follows:


1. Press  key to start lock, and then enter the Verify State.
2. Press and hold the  key until you hear 1 long beep, enter the 5 digits MPC, and then press  key to enter the Management Mode.
3. Press "9" on the lock to enter the Enroll Administrator Mode.

The next step is to enroll fingerprint and password for administrator. Please see **2.2.1 Enroll a Fingerprint Administrator User** and **2.2.2 Enroll a Password Administrator User**.

#### 2.2.1 Enroll a Fingerprint Administrator User



**Note:** 1-3 steps are same as above. Here is no longer to restate.

4. After enter the Enroll Administrator Mode, press number keys of the lock to enter 3 digits user ID, and then press  key to confirm.



**Note:** The administrator User's ID must between "995" and "999".

5. Press finger in the scanner area properly (For detail, please see [1.5 Finger Placement](#)), and repeat it for three times, until you hear one long beep and LED

flashes Green.



**Note:** During the collect process, if success collects the fingerprint, the



key flash color light. If not, namely fingerprint-gathering failure, it shall continue to press the fingerprints, so that the lock success collects 3 times.




**Note:**



- (1) If Fingerprint lock fails to register. It will give 2 short beeps and the LED will flash red. If failed in registered, you can try again for two more time.
- (2) If register successful, it will automatically exit the Enroll Administrator Mode.
- (3) Press and hold "0" key, can exit anytime.
- (4) If you want to enroll more administrator user, then repeat the step 1-5.

### 2.2.2 Enroll a Password Administrator User



**Note:** 1-3 steps are same as above. Here is no longer to restatement.

4. After enter the Enroll Administrator Mode, enter 3 digits user ID, press  key to confirm.

5. Press 4 digits user password and press  key to confirm, and then enter the 4 digits user password once again and press  key to confirm, until you hear one long beep and LED Flashes Green (If it fails to register – it will give 2 short beeps and LED will flash red).



**Note:**

- (1) If Pass code does not match it will fail registration. In this case you will need to follow step 1 to 5 again.
- (2) If successful, it will automatically exit the Enroll Administrator Mode.
- (3) Press and hold "0" key, can exit anytime.
- (4) If you want to enroll more administrator user, then repeat the step 1-5.





### 2.3 Enroll an ordinary User



**Note:** You must change the MPC and enroll an administrator user at first, otherwise you can't enroll ordinary user.

#### 2.3.1 Enroll a Fingerprint Ordinary User

The specific procedure is as follows:

1. Press  key to start the lock and enter the Verify State.
2. There have two methods to enter the Management Mode:
  - (1) Press and hold the  key until you hear 1 long beep, enter the 5 digits MPC, and then press  key to enter the Management Mode.
  - (2) Verify the registered administrator's password and fingerprint (please see [2.4 User Verification](#)) to enter the Management Mode.
3. Press "1" to enter the Enroll Ordinary User's Fingerprint Mode.
4. Input 3 digits User ID, then press  key to confirm.



**Note:** The ordinary users' ID must between "001" and "994".

5. Press finger in the scanner area properly (For detail, please see [1.5 Finger Placement](#)), and repeat it for three times, until you hear one long beep and LED flashes Green, namely enrollment successful.



**Note:**



(1) If fingerprint fails to register - the buzzer will give 2 short beeps and LED flashes red. If failed in registered, you can try again for two more time.

(2) If successful, it will automatically exit the Enroll Ordinary User's Fingerprint Mode.

(3) Press and hold "0" key, can exit anytime.



(4) If you want to enroll more ordinary user, then repeat the step 1-5.

### 2.3.2 Enroll a Password Ordinary User

1. Press  key to start the lock and enter the Verify State.
2. Enter the Management Mode, please see [2.3.1 Enroll a Fingerprint Ordinary User](#).
3. Press "2" on the lock to enter the Enroll Ordinary User's Password Mode.
4. Input 3 digits User ID, and press  key to confirm.



**Note:** The ordinary users' ID must between "001" and "994".

5. Input 4 digits user password, press  key to confirm. Enter the 4 digit user password once again and press  key to confirm until you hear one long beep and LED flashes Green. The Keypad area's blue LED put out. If it fails to register -

it will give 2 short beeps and LED will flash red.






**Note:**

- (1) If Pass code does not match it will fail registration. If you want to continue, can press and hold "0" key to quit, and return to the step 1 to continue enroll.
- (2) If successful, it will automatically exit the Enroll Ordinary User's Password Mode.
- (3) If you want to enroll more Password Ordinary User, then repeat the step 1-5.


### 2.4 User Verification


The users can user fingerprints or passwords verification to unlock.


#### 2.4.1 The Fingerprint Verification


1. Press  key to start the lock and enter the Verify State. The **Fingerprint Collector** is in active state.
2. Press finger in the fingerprint scanner area properly (For detail, please see [1.5 Finger Placement](#)), until you hear one long beep, namely collect successful.
  - (1) If verify successful, the buzzer will give a long beep and unlock, the Green LED at  key will light for 3 seconds, the green LED at **Fingerprint Collector** will light for 5 seconds.
  - (2) If verification failed. The buzzer will give two short beeps, the red LED at  key will light for 3s, then the green LED will flash, the user can use fingerprint to verify again until verify successful.

### 2.4.2 The Password Verification


1. Press  key to start the lock and enter the Verify State.

2. Press number key of lock to input the correct 4 digits password, and press  key to confirm.

(1) If the password is correct, then verify successful, the buzzer will give a long beep and unlock, the Green LED at  key will light for 3s, the green LED at fingerprint scanner will light for 5s.

(2) If the password is wrong, then the verification failed. The buzzer will give two short beeps, the RED LED at  key will light for 3s, then the green LED will flash, the user can input password to verify again until verify successful.




**Note:** After successful verification, the lock is in unlocking state. If you want to lock, press  key to start the lock, and then press this key again to lock and power off.

## 2.5 Delete User

### 2.5.1 Delete a user

**The procedure show as follows:**

1. Press  key to start the lock and enter the Verify State.

2. Enter the Management Mode, please see [2.3.1 Enroll a Fingerprint Ordinary User](#)






## 2. The Basic Operation

---

3. Press "3" on the lock to enter the Delete User Mode.

4. Press number key of the lock to input the User's ID which one you want to delete,

and then press  key to confirm. Input the user ID again, and press 

key to confirm, the buzzer will give a long beep, the  key flashes green light,

namely successful delete the user.


5. After deleting the user, you can restart the fingerprint lock and verify the deleted user's fingerprints or password again to check whether the user is deleted for sure.



**Notice:** The administrator can't delete itself and the last administrator.


### 2.5.2 Delete All Ordinary Users



The procedure show as follows:

1. Press  key to start the lock and enter the Verify State.

2. Enter the Management Mode, please see [2.3.1 Enroll a Fingerprint Ordinary User](#)

3. Press "6" on the lock to enter the Delete All Ordinary User Mode.

4. Input "000" and press  key to confirm, then input "000" again and press





 key to confirm. The buzzer will give a long beep, the  key flash green light, namely successful delete all users.



**Notice:** The operation can only delete ordinary users. If you want to delete administrator, you should do reset operation, for detail, please see [2.7 Reset Lock to Factory Default Settings](#).

### 2.6 Enable / Disable a User

The procedure show as follows:

1. Press  key to start the lock and enter the Verify State.
2. Enter the Management Mode, please see [2.3.1 Enroll a Fingerprint Ordinary User](#).
3. Press "4" on the lock to enter the Enable/Disable User Mode.
4. Press the number keys on the lock to input the user's ID which one you want to enable or disable, press  key to confirm, input the user ID again and press  key to confirm. The buzzer will give a long beep and the  key flashes green light, namely enable or disable this user.





#### Notice:

- (1) You can only enable or disable ordinary user.
- (2) The disable user can't do Verify operation, namely can't unlock.



### 2.7 Reset Lock to Factory Default Settings


The procedure show as follows:

1. Press  key to start the lock and enter the Verify State.
2. Enter the Management Mode, please see [2.3.1 Enroll a Fingerprint Ordinary User](#).
3. Press "7" on the lock to enter the Reset Settings Mode.
4. Input "0000" and press  key to confirm, input "0000" again and press

## 2. The Basic Operation

---

 key to confirm. The buzzer will give a long beep and the  key flashes green light, and then reset the lock's settings to factory default.

 **Note:** After reset the lock's settings, the MPC will reset as "98989" (The factory default MPC), and delete all users in the lock (contents the Administrator and Ordinary users)

## 3 Conventions on Other Functions

### 3.1 Routine Operation Indications

**User operation success indication:** The buzzer sounds once and the green LED indicator is solid on for 3 seconds.

**User operation failure indication:** The buzzer sounds short tone twice and the red LED indicator is solid on for 3 seconds.

**Verify State:** Green LED flash by second. Blue LED will light on.

**Management Mode:** Blue LED flash by second. Green LED put out.

**Warning indication:** The buzzer sounds short tone five times intermittently.

Note:




**Note:** Only when the blue background light of the keyboard is on or flashed can enter numbers, such as passwords, user's identification or master password.

### 3.2 Initialization Lock

When the user forget the whole password you had registered, and the fingerprint can't be used, then you can user Initialization key to initialization lock.

Use the screwdriver take down the screws in the back of lock cover, then press the Initialization Key to Initialization Lock (reset the lock to factory default settings).


Show as below:



**Initialization Key**

### 3.3 Unlock the Non-lock Status Alarm

The non-lock status alarm can be switched off in the following two situations:

1. Press the  button and the machine will lock automatically. The alarm will sound continuously until the non-lock status is released after the proper locking is done.
2. Lock it by the mechanical key or by the lock button inside. The alarm will be

switched off after the proper locking is done.


### **3.4 Automatic Program Exit and System Power-off**

- The Fingerprint Lock powers off automatically upon successful matching and unlocking.
- The Fingerprint Lock powers off automatically when the supply voltage is too low.
- The Fingerprint Lock powers off automatically if there is no keystroke within 10 seconds on the initial interface.
- After successful verification, press key to start the lock, and then press this key to unlock and power off.

### **3.5 Use Description of External Power**

The Fingerprint Lock supports temporary use of external DC power for fingerprint or password matching and unlocking, but when connected with an external battery, the fingerprint lock cannot provide such special functions as enrollment, deletion and setting, so as to prevent data loss as a result of power instability.

As shown in the figure below, connect a 6V battery to the two access points at the bottom of a fingerprint lock, regardless of polarity.



If you power off a Fingerprint Lock without closing the lock during the use of external power, the lock cylinder will not automatically return to its original position. That is, the Fingerprint Lock remains in **unlock** state. To solve this problem, you can replace the battery and then open the lock once to have the lock cylinder in position.


### 3.6 Unlock With an Emergency Mechanical Key

You can open the door using an emergency mechanical key in case the electronic component does not operate.


- ① Use your fingernails or a hard chip to take down the lock cover.

② Insert the emergency key into the keyhole and rotate 90° to unlock.

①



②



**Note:** The key shown in the figure is not a real object; please use the key provided with the device. After unlock, please replace the lock cover.

### 3.7 Battery Low Voltage Protection

When the battery is low, there are alarm signals to warn users to change the battery as follows:

1. When the battery voltage is lower than 4.8V, the buzzer will make short sharp sounds for five times when starting the machine. Users can unlock it normally but fail to enter the administrative mode.



2. When the battery voltage is lower than 4.5V, the buzzer will make short sharp sounds for five times, and then the machine will be switched off automatically.



**Note:** When the low-voltage alarm occurs, please change the battery in time to avoid the impact on the work of the fingerprint lock. Avoid losing data caused by instable power supply (It is suggested to change the battery immediately when the battery voltage is lower than 4.8V).

## 4. Appendix

### 4.1 The Parameter Table

**BL100** Fingerprint Lock basic function parameters are shown as below:

<b>Item</b>	Description
<b>Power</b>	DC 6V
<b>Capacity</b>	100 users (100 fingerprints)
<b>Collector</b>	Optical Fingerprint Collector
<b>Algorithm Version</b>	10.0
<b>LED</b>	Three colors (red, green, blue) instructions

## **4.2 Statement on Human Rights and Privacy**

### **Dear Customers:**

Thank you for choosing the hybrid biometric products designed and manufactured by us. As a world-renowned provider of biometric technologies and services, we pay much attention to the compliance with the laws related to human rights and privacy in every country while constantly performing research and development.

### **We hereby make the following statements:**

1. All of our fingerprint recognition devices for civil use only collect the characteristic points of fingerprints instead of the fingerprint images, and therefore no privacy issues are involved.
2. The characteristic points of fingerprints collected by our products cannot be used to restore the original fingerprint images, and therefore no privacy issues are involved.
3. We, as the equipment provider, shall not be held legally accountable, directly or indirectly, for any consequences arising due to the use of our products.
4. For any dispute involving the human rights or privacy when using our products, please contact your employer directly.

Our fingerprint products for police use, or development tools support the collection of the original fingerprint images. As for whether such a type of fingerprint collection constitutes an infringement of your privacy, please contact the government or the final equipment provider. We, as the original equipment manufacturer, shall not be held legally accountable for any infringement arising thereof.

The law of the People's Republic of China has the following regulations regarding the personal freedom:

1. Unlawful arrest, detention or search of citizens of the People's Republic of China is prohibited; infringement of individual privacy is prohibited.


#### 4. Appendix

---

2. The personal dignity of citizens of the People's Republic of China is inviolable.
3. The home of citizens of the People's Republic of China is inviolable.
4. The freedom and privacy of correspondence of citizens of the People's Republic of China are protected by law.

At last we stress once again that biometrics, as an advanced recognition technology, will be applied in a lot of sectors including e-commerce, banking, insurance and legal affairs. Every year people around the globe suffer from great loss due to the insecurity of passwords. The biometric products actually provide adequate protection for your identity under a high security environment.

### 4.3 Environment-Friendly Use Description

	<p>The Environment Friendly Use Period (EFUP) marked on this product refers to the safety period of time in which the product is used under the conditions specified in the product instructions without leakage of noxious and harmful substances.</p> <p>The EFUP of this product does not cover the consumable parts that need to be replaced on a regular basis such as batteries and so on. The EFUP of batteries is 5 years.</p>					
<b>Names and Concentration of Toxic and Hazardous Substances or Elements</b>						
Parts Name	Toxic and Hazardous Substances or Elements					
	Pb	Hg	Cd	Cr6+	PBB	PBDE
Chip resistor	×	○	○	○	○	○
Chip capacitor	×	○	○	○	○	○
Chip inductor	×	○	○	○	○	○
Chip diode	×	○	○	○	○	○
ESD components	×	○	○	○	○	○
Buzzer	×	○	○	○	○	○
Adapter	×	○	○	○	○	○
Screws	○	○	○	×	○	○
<p>○: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in SJ/T11363-2006.</p> <p>×: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials for this part is above the limit requirement in SJ/T11363-2006.</p> <p><b>Note:</b> 80% of the parts in this product are manufactured with non-hazardous environment-friendly materials. The hazardous substances or elements contained cannot be replaced with environment-friendly materials at present due to technical or economical constraints.</p>						